



## NOON

### ASSEMBLY INSTRUCTIONS 11/2011

NOON lamps are precision made by hand in a small workshop. The steel frames are DD laquered. Fingerprints occasioned during assembly can be wiped off with a soft cloth.

#### ASSEMBLY

Assembly and repairs may only be carried out by a qualified electrician.

- NOON1           Screw the bracket to the ceiling, adjust the cable to the required length. Shorten the cable, then pull the cover up along the cable to hide the bracket and fixate it.
- NOON 2, 5, 12   Fix to the ceiling using the screws provided.
- READ NOON       Fit the foot to the shaft and tighten with the M12 allen-screw.
- HIGH NOON       Fit the foot to the shaft and tighten with the M12 allen-screw. Open the adjusting screw, adjust the arm to the required height and tighten again (minimum 160 cm to maximum 210 cm). The brightness can be regulated using the dimmer.
- WALL NOON       Unscrew M3 counter sunk bolts on upper and lower side of the back panel. Pull cover from back panel. Mount back panel and connect lamp to power. Push the cover back on the back panel and fix with counter sunk bolts M3 from both sides.