

BONDT

ASSEMBLY INSTRUCTIONS 04/2011


REQUIRED TOOLS:

Hexagon key (included)

16 x XS Connector with

 steel-dowel

 box

 grub screw

Prior to assembly insert and turn steel-dowels into pieces A and B. Insert the boxes into all the other planks, longitudinal slot must parallel to the long side of the plank.

ASSEMBLY OF THE FRAME

To fix the connectors please use the grub screws. If you cannot screw in the grub screw flushly, loosen connection and unscrew the steeldowel slightly. Then connect again.

1. Connect plank E to plank A and fix. Then connect plank C to A and fix.
2. Connect plank F to plank B and fix. Then connect plank D to B and fix.
3. Cross and join the two mounted pieces.
4. Connect and fix remaining parts A and B to frame.

Make sure to tighten all connections once more.

SCREWING THE TABLE TOP ON THE FRAME

Spread a blanket, put the table to upside down on the blanket. Position the frame on the table top and fix with enclosed pan-head screws.

